


MetroNet Devices

There are several devices in your MetroNet package. The photos below identify them with a brief description of each.



Fiber optic cable carrying TV and Internet signal into your home

Nokia fiber modem/optical network terminal (ONT)

ZyXEL wi-fi router for connecting computer, tablet, smartphone to wireless network. On the back is a sticker with your network name(s) and the password.



CISCO set top box (STB) controlling your TV. Your remote control interacts with this.




Set top box with Digital Video Recorder (DVR). Your remote control interacts with this.

Remote control



Remote Control

BUTTON FUNCTIONS



BUTTONS SHOULD BE PRESSED AND RELEASED QUICKLY, AS HOLDING BUTTONS MAY EXECUTE ADDITIONAL COMMANDS.